

STM-8100 BT

REV. A

# 승 인 원

품 명	Bluetooth Chip Antenna
모델명 / 대역	STM-8100
품 번	M530301
고 객 명	Woongjin ST
공 급 처	에더트로닉스

회	로	기	구	품	질
담 당	팀 장	담 당	팀 장	රා රා	팀 장
CS YOON	Mit.	frank.	Swend	Many	923
윤천수	김기수	설철훈	최승웅	왕명호	박준호



경기도 군포시 당정동 522 SK 벤티움 101 동 601 호~602 호

Tel: 031-436-2290~2 Fax: 031-436-2293 WWW.ETHERTRONICS.COM



## STM-8100 BT

REV. A

### 목 차

1.	이력관리	3
2.	전기적 특성	4
	2.1. SET 정재파비 (VSWR)	4
	2.2 SET 복사 패턴 (Radiation Pattern)	5
	2.3 안테나 이득	
	2.4 방사 패턴	6
	2.4.1 Woongjin ST STM-8100 Model Bluetooth band (H-plane)	6
	2.4.2 Woongjin ST STM-8100 Model Bluetooth band (E1-plane)	
	2.4.3 Woongjin ST STM-8100 Model Bluetooth band (E2-plane)	
3.	기구적 특성	
	3.1. 부품의 규격	
	3.2. LOT 번호 마킹	
4.	시험 방법	
	4.1 SWR/Return Loss	
	4.2 Gain	
	특성검사(VSWR) 검사지그 측정 DATA	
	신뢰성 보증 조건	
	신뢰성시험 성적서	
8.	납땜조건	
	8.1 REFLOW 조건	
	8.2 수동 납땜 조건	
	8.3 PCB PATTERN 의 설계	
9.	구조 및 재질	
	9.1 도면	
	9.2 PART LIST	
10.	주의사항	
	10.1 보관조건	
	10.2 취급 및 운송	
11.	포장사양	
	11.1 Carrier Tape & Reel 사양	
	11.2 Carrier Tape Drawing	
	11.3 Reel Drawing	
	11.4 Box 사양	
	관리공정도	
13.	유해 물질 성적서	
	13.1 세라믹 파우더	
	13.2 Au plating	
	13.3 Ni plating	
	13.4 Ag Paste	
	13.5 Marking Paste	38



STM-8100 BT

REV. A

## 1. 이력관리

חבע אס	ᅰ져이피	חאפר	개정	개정사항			
REV NO.	개정일자	PAGE	개정 전	개정 후	개정사유		



STM-8100 BT

REV. A

### 2. 전기적 특성

### 2.1. SET 정재파비 (VSWR)

안테나는 전기적 사양에 명시되어 있는 정재파비 요구사항을 만족 해야 한다

주파수 대역 (Frequency Range) 2,400 배 단말기 정재파비 5,27:10년		2,450 MHz	2,480 MHz	
단말기 정재파비 (V.S.W.R)	5.37:1 이하	1.58:1 이하	4.2:1 이하	



그림 1: Testing with network analyzer




그림 2: Return Loss and VSWR



STM-8100 BT

REV. A

### 2.2 SET 복사 패턴 (Radiation Pattern)

안테나의 복사 패턴은 수직면에서 무 지향성 패턴을 가져야 한다.

### 2.3 안테나 이득

안테나의 Gain 과 효율성을 실험하기 위해 셋트에 조립되어야 하며, 완전히 조립되고 작동하는 STM-8100모뎀에서 테스트 되어져야 한다. 안테나는 무 반향실의 free space에서 H,E1,E2 플랜에 의해 테스트가실시되어야 한다. 안테나 지향성도는 전달/수용 밴드(transmit and receive bands) 중앙에서 측정되어야 한다.

주파수 다 ( Frequency		2,400 MHz	2,450 MHz	2,500 MHz		
단말기 정 (V.S.W.F		5.37:1 이하 1.58:1 이하		4.2:1 이하		
검사 지그 정	재파비	1,900 MHz	1,960 MHz	2,020 MHz		
(V.S.W.F	٦)	5.1:1 이하	2.1:1 이하	4.3:1 이하		
	H-Plane	-9.40	-6.15	-8.33		
최대 이득 (Gain)	EI-Plane	-8.05	-5.09	-7.75		
	E2-Plane	-12.24	-8.63	-10.63		
공칭 임피	던스	50 Ω				
편파		수직				
복사패턴	<u> </u>		무지향성			




그림 3: Geometry for STM-8100 for radiation pattern




STM-8100 BT

REV. A

### 2.4 방사 패턴

### 2.4.1 Woongjin ST STM-8100 Model Bluetooth band (H-plane)




Layer	Max value	Position	Min value	Position	BeamWidth	Average
2400(MHz)	-5.23 dB	14.07 deg	-16.20 dB	272.78 deg		-9.40 dB
2410(MHz)	-4.49 dB	14.07 deg	-15.21 dB	272.78 deg		-8.65 dB
2420(MHz)	-3.65 dB	14.07 deg	-14.24 dB	300.96 deg		-7.78 dB
2430(MHz)	-2.98 dB	14.07 deg	-13.53 dB	300.96 deg		-7.21 dB
2440(MHz)	-2.22 dB	14.05 deg	-12.91 dB	300.93 deg		-6.57 dB
2450(MHz)	-1.86 dB	14.05 deg	-12.79 dB	300.93 deg		-6.15 dB
2460(MHz)	-1.85 dB	11.25 deg	-12.53 dB	300.94 deg		-6.14 dB
2470(MHz)	-2.12 dB	11.25 deg	-12.56 dB	300.94 deg		-6.41 dB
2480(MHz)	-2.90 dB	11.25 deg	-13.29 dB	300.94 deg		-7.12 dB
2490(MHz)	-3.52 dB	11.25 deg	-13.63 dB	300.94 deg		-7.67 dB
2500(MHz)	-4.12 dB	11.25 deg	-14.04 dB	300.94 deg		-8.33 dB



STM-8100 BT

REV. A

### 2.4.2 Woongjin ST STM-8100 Model Bluetooth band (E1-plane)




Layer	Max value	Position	Min value	Position	BeamWidth	Average
2400(MHz)	-4.56 dB	117.14 deg	-17.73 dB	160.01 deg	43.25 deg	-8.05 dB
2410(MHz)	-3.58 dB	120.00 deg	-16.72 dB	160.01 deg	40.56 deg	-7.30 dB
2420(MHz)	-2.52 dB	120.00 deg	-16.00 dB	160.01 deg	40.01 deg	-6.41 dB
2430(MHz)	-1.78 dB	117.14 deg	-15.83 dB	160.01 deg	38.91 deg	-5.86 dB
2440(MHz)	-0.95 dB	117.14 deg	-14.45 dB	162.85 deg	38.71 deg	-5.35 dB
2450(MHz)	-0.77 dB	117.14 deg	-14.63 dB	160.01 deg	38.92 deg	-5.09 dB
2460(MHz)	-0.94 dB	117.14 deg	-14.91 dB	160.01 deg	39.78 deg	-5.07 dB
2470(MHz)	-1.40 dB	71.43 deg	-16.26 dB	160.01 deg	54.57 deg	-5.47 dB
2480(MHz)	-2.07 dB	71.43 deg	-17.00 dB	159.99 deg	54.56 deg	-6.22 dB
2490(MHz)	-2.68 dB	117.14 deg	-18.02 dB	159.99 deg	40.55 deg	-6.94 dB
2500(MHz)	-3.28 dB	71.43 deg	-19.65 dB	159.99 deg	55.68 deg	-7.75 dB



STM-8100 BT

REV. A

### 2.4.3 Woongjin ST STM-8100 Model Bluetooth band (E2-plane)



Layer	Max value	Position	Min value	Position	BeamWidth	Average
2400(MHz)	-8.72 dB	57.14 deg	-19.68 dB	-60.00 deg	148.59 deg	-12.24 dB
2410(MHz)	-7.95 dB	60.00 deg	-19.01 dB	-60.00 deg	149.90 deg	-11.34 dB
2420(MHz)	-6.86 dB	54.29 deg	-17.49 dB	-57.16 deg	149.92 deg	-10.33 dB
2430(MHz)	-6.20 dB	54.29 deg	-17.49 dB	-57.14 deg	163.71 deg	-9.61 dB
2440(MHz)	-5.73 dB	48.57 deg	-16.39 dB	-57.16 deg	157.87 deg	-8.93 dB
2450(MHz)	-5.48 dB	45.71 deg	-15.52 dB	-57.16 deg	162.85 deg	-8.63 dB
2460(MHz)	-5.45 dB	42.86 deg	-15.15 dB	-57.14 deg	167.38 deg	-8.49 dB
2470(MHz)	-5.86 dB	42.86 deg	-15.47 dB	-57.14 deg	170.37 deg	-8.81 dB
2480(MHz)	-6.63 dB	45.71 deg	-15.77 dB	-57.14 deg	169.37 deg	-9.45 dB
2490(MHz)	-7.32 dB	57.14 deg	-16.40 dB	-57.14 deg	174.45 deg	-9.95 dB
2500(MHz)	-7.89 dB	45.71 deg	-16.56 dB	-54.30 deg	175.85 deg	-10.63 dB



STM-8100 BT

REV. A

### 3. 기구적 특성

### 3.1. 부품의 규격

항 목	SPEC.	REMARK
내부전극	Ag	Pb-free
외부전극	Ag/Ni/Au	Pb-free
치 수	5.0(L)x3.0(W)x1.08 (H)	mm
무 게	0.05±0.01	g
동작온도	-35 ~ +85	°C




STM-8100 BT

REV. A

### 3.2. LOT 번호 마킹

### LOT-NO 표기 방법



### 2. LOT NO 표기 설명

### 1) 제조연도 표기 예

제조연도	2006	2007	2008	2009	2010	2011	2012	2013	2014	2015
표기	6	7	8	9	0	1	2	3	4	5

### 2) 제조주 표기 예

제조주	1	2	3	4	5	6	•••	50	51	52	53	54
표기	1	2	3	4	5	6	•••	50	51	52	53	54



STM-8100 BT

REV. A

### 4. 시험 방법

### 4.1 SWR/Return Loss

Network Analyzer 를 이용하여 SWR/Return Loss 를 측정하고 표본 Sample 을 선별 후 검사 지그를 사용하여 양품과 불량품을 선별한다.

	Set Condition	JIG Condition
Network Analyzer	Agilent E5071C (ENA)	Agilent E5071C (ENA)
Cable	RF Cable (400mm)	RF Cable (400mm)
Test Condition	Apartmental Mile Control Contr	




STM-8100 BT

REV. A

### 4.2 Gain

당사가 보유한 전자파 무반사실을 이용하여 Antenna Gain을 측정한다.

### Anechoic Chamber for antenna Gain Measurement







STM-8100 BT

REV. A

### 5. 특성검사(VSWR) 검사지그 측정 DATA



### STM-8100 BT Antenna VSWR CPK

		검사 지그	V,S,W,R	
	1,900MHz	1,960MHz	2,020MHz	Remark
NENO	5,1:1이하	2,1:1이하	4,3:1이하	
1	4.2	1.6	3.1	
2	4.0	1.5	3.2	
3	4.2	1.6	3.2	
4	4.0	1.5	3.5	
5	3.5	1.6	4.0	
6	4.3	1.6	3.0	
7	4.8	1.8	2.6	
8	4.4	1.6	3.0	
9	4.5	1.7	2.9	
10	4.4	1.6	3.0	
11	4.4	1.6	3.1	
12	4.8	1.7	2.7	
13	4.7	1.7	2.8	
14	4.1	1.5	3.4	
15	4.4	1.6	3.0	
16	4.3	1.6	3.1	
17	4.8	1.8	2.7	
18	3.9	1.5	3.6	
19	4.0	1.5	3.4	
20	4.2	1.6	3.1	
USL	5,1	2,1	4,3	
LSL				
Xbar	4,3	1,6	3,1	
Max	4,80	1,80	4,00	
Min	3,50	1,50	2,60	
B	1,30	0,30	1,40	


 $Ether tronics, Inc.\ Confidential\ \&\ Proprietary$ 



STM-8100 BT

REV. A

### 6. 신뢰성 보증 조건





STM-8100 BT

REV. A

## 7. 신뢰성시험 성적서

	68.75	ar Issues Sanson	to a design and the second	100 100 100	600		657MS-80	570)		Frai	ming	Invest	igation	Ар	proval										
	JF	Reliab	ility T	est F	Rep	ort	(A	.)		Mar.	ns s	6A		B	23										
	SUPP	LIER	ethertr	onics	CUST	OMER	SAMSUNG	SELECTRO-N	MECHANICS	DA	NTE.	20	09.3.15	~ 2009	.3.28										
	MODEL	NAME	STM-81	100 BT	ETHER	CODE		M53030	1	INSPE	CTOR		Wang, I	Myung F	ło										
200	1.0000000	100	Inspection	000000000					Re	sult		***			8										
No	Division	Item	sort	SPEC	×1	×2	Before ×3	×4	×5	×1	×2	After ×3	×4	X5	Judgment										
			appearance	no error	ок	ок	ок	ок	ок	ок	ок	ок	ок	ОК	OK										
-1		High Tanan		1,900Mz less than 5.1:1	4.2	4.0	4.0	4.8	4.7	4.3	4.1	4.0	4.8	4.6	ок										
1,		High Temp.	V.S.W.R	1,960Mb less than 2.1:1	1.6	1.5	1.5	1.6	1.5	1.6	1.7	1.5	1.6	1.7	ок										
				2,020Mb less than 4.3:1	3.1	3.2	3.5	3.0	3.1	3.2	3.4	3.5	3.1	3.2	ок										
		appearance	no error	ок	ок	ок	ок	ок	ок	ок	ок	ок	ок	ок											
2	E n v i r	LowTown	ow Temp. V.S.W.R	1,900Mb less than 5.1:1	4.1	4.0	4.1	4.6	4.7	4.3	4.3	4.1	4.7	4.6	ок										
2	o n m e n	Low Temp.		1,960Mb less than 2.1:1	1.6	1.6	1.5	1.6	1.5	1.6	1.6	1.5	1.6	1.6	ок										
	1	t												2,020Mb less than 4.3:1	3.2	3.2	3.6	3.3	3.2	3.2	3.4	3.5	3.4	3.1	ок
	High Temp.	appearance	no error	ок	ок	ок	ок	ок	ок	ок	ок	ок	ок	ок											
			1,900Mb less than 5.1:1	4.2	4.1	4.1	4.5	4.5	4.1	4.2	4.2	4.5	4.8	ок											
3		& High Hum.	V.S.W.R	1,960Mb less than 2.1:1	1.4	1.5	1.5	1.7	1.5	1.5	1.5	1.5	1.6	1.6	ок										
				2,020Mb less than 4.3:1	3.2	3.2	3.1	3.2	3.4	3.1	3.1	3.2	3.4	3.4	ок										



STM-8100 BT

REV. A

#### Reliability Test Report (B) Inspection Division SPEC Item Before After Judgment ×1 ×з $\times 4$ ×5 X2 ×з ×5 $\times 2$ $\times 1$ $\times 4$ appearance no error OK OΚ OΚ OK ΟK OΚ OK OΚ OK OK ok Environment 1,900₩₺ less than 5.1:1 4.3 4.0 4.0 4.8 4.7 4.0 4.6 ok 4.3 4.1 4.8 Salt spray 4 test 1,960Mb less than 2.1:1 V.S.W.R 1.6 1.5 1.5 1.5 1.6 1.6 1.5 1.5 oĸ 2,020Mb less than 3.3 3.2 3.1 3.4 3.1 3.5 3.1 3.2 3.1 3.3 ok 4.3:1 a c h i n a r y not 5 OK. OK OK OK OK ok Drop test appearance seperated T e s t Remark




STM-8100 BT

REV. A

### 8. 납땜조건

### 8.1 REFLOW 조건

REFLOW 조건은 아래의 온도 및 시간을 따른다.




#### 8.2 수동 납땜 조건

제품에 인두기를 직접 접촉하여 땜하지 않는다. 제품을 120°C에서 60~250초 동안 예열 후 인두온도 250°C~280°C로 작업한다.


#### 8.3 PCB PATTERN의 설계

PCB PATTERN은 칩 안테나 PATTERN의 외곽 크기 보다 0.1MM 크게 설계한다.



athertropics	승 인 원	
ethertronics shaping antenna technology	STM-8100 BT	REV. A

9. 구조 및 재질 9.1 도면





STM-8100 BT

REV. A

### 9.2 PART LIST

품명	재질	원료 업체	색상	가공 업체	가공 방법	후가공	후가공 업체	수량
CHIP ANTENNA	Er=9.1	1	GRAY	RN2	LTCC	도금 Ni: 2~5um Au: 0.03um 이상	1	1

원료	품 명	구성물질	CAS #.		
POWDER	X-200	GLASS FRIT	6599-17-3		
	7875	Silver	7440-22-4		
	내/외부전극	Diethylene glycol monobutyl ether	112-34-5		
금도금액		Silver powder	7440-22-4		
0 7 0 7	7454B	Ethyl cellulose	9004-57-3		
	Via 전극	Via 전극 Diethylene glycol monobutyl ether			
		Terpineol	98-55-5		
		차아인산나트륨 (NaH2PO2.H2O)	7681-53-0		
니켈도금액	NIPEL PMF- 2000	황산니켈(NISO4.6H2O)	7786-81-4		
		수산화나트륨 (NaOH)	1310-73-2		
PATTERN	Auruna	Au	_		



STM-8100 BT

REV. A

### 10. 주의사항

#### 10.1 보관조건

제품을 온도가 높거나 습도가 높은 장소에서 떨어진 곳에 보관할 것. 40°C 이상의 고온방치 시 포장재에 변형이 발생될 수 있음. 제품을 부식성의 가스(황화수소, 아황산, 염소, 암모니아 등)로부터 떨어진 곳에 보관할 것. 보관장소의 온도는 5 ~ 35°C, 습도는 45 ~ 75% RH 일 것. 보관기간은 포장일로부터 6개월 이내일 것.

### 10.2 취급 및 운송

제품에 충격 또는 힘이 가해 지지 않도록 주의할 것. 납땜 부위는 이물이 묻지 않도록 주의할 것.



STM-8100 BT


REV. A


### 11. 포장사양

### 11.1 Carrier Tape & Reel 사양


품 명	재 질	표면 저항	포장방식
Carrier Tape	Antistatic PET	10**8Ω	열 압착 방식
Cover Tape	PET	10**8Ω	2 47 67
Reel	PS	10**8Ω	

### 11.2 Carrier Tape Drawing





### 11.3 Reel Drawing






STM-8100 BT

REV. A














STM-8100 BT

REV. A

### 12. 관리공정도



Ethertronics, Inc. Confidential & Proprietary





STM-8100 BT

REV. A

				면서면	ETP-H-01-176	176		₹0 ŘГ	70	Ш	송
Athon		1	しまけ(v v)	PART - NO			双则	100		ě.	-
etaing enterna technology	one teachwatery?	マ	세소 (W.V) 하징노	80 ₹0 ⊟0	부품사업부	DI-	吞		B	Collens	\$ 125 CC
				田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田田	Antenna	et					
H (0) (0) (0)	四 (内)	明 公 六 八	五名小尺	자	公公		근라		立 5 5 5 5 6	Ξ	L-
사내 외주				<del>1</del> 0	기종	GF 600	<u>₹</u>	票		ī	ı
	日間版文	80 10	(明報 ) 등 (기계 ) 기계 (기	0\$T \$1	書号 Lot일加	χι It	GF Lot	国際紹介	20 20 20 20	五年 東京	<b>製</b> 到
		80 Mr Mo RN	질량계부 오차점위대의사 추장 축 투인	西 部 河	오차병유내	₹0 20	전 전 전	高 (20) (40)	사 전 전	*졌을 투입 전 이상 시 해당관리자 보고.	(2) (2) (3) (4) (4) (4)
		사 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전	1차 조합 후 슬라리 출토 잔 온도계 삼입	는 UH WU		UH UH	전 참 품	のののでは、	다 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전	(N) (表) (表) (表)	F3.01%
2	KI	計劃	슬러리 발포랭크에 출토 후 탈포기 작동 및 교반.	の原理	(-0.08±0.02)mpa (45±15) min	20 전 전 전	된 성 전	10000000000000000000000000000000000000	A MO	시 해당 관리자에게 보고.	의자에게
)—		数 例 数	캐스팅 전 슬라리 출토(150cc) 후 5±2 MiN 이내 측정	西山和	(8P4,20)rpm (170±50cP)	₹0 <b>2</b> 0	전 전 전	での	(R)	*정도기,일도기 이상	도기 이상
		의 해 전	1차 조합 종료 후 시료를 임도 분석기로 측정	임도분석기	d(0.5):2.434±0.5µm d(0.9):6.135±1.5µm	20 20	전 전 전	(A) (A) (A)	AL SIII	는 등 이 대한 학교 등 등 등 등 등 등 등 등 등 등 등 등 등 등 등 등 등 등	K 1874 IZ
(8)	Casting	Sheet 두께 상태 (CTQ)	Sheet 두게 감사	Height 게이지	UF中:78±1μm Cover:91±1μm	中別	시업 시 두꺼전환시	(40 (40 (40 (40 (40 (40 (40 (40 (40 (40	호 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전 전		
4	Sheet	Sheet Cutting 상태	Sheet 절단 후 최초 작업 Sheet상단 확인.(Size/외관 상단)	0\$T \$1	기로:160±3mm 세로:160±3mm	₹0 ₹0	정	무리점사	왕 다	*시트 사이즈 이상 시 Sheet 절단 이송 거리 조정.	즈 이상 시 이송 거리
_(			작용 장수 설비 디스플레이 확인	야 주1	내부-5장 Cover-1장	<b>⊹</b>	A M	관리점사	사 전 전		
5	400 RI	Sheet 28 @	가양 시간 디스플레이 확인			412t	시험시		장임자		
)			가약 온도 인디게이면 책인	邮		UH OU	AIN AI	관리점사	A MA		
			그런 한 민디지의 화학	0#T		TO OIL	12 12 130		다 R		





STM-8100 BT

REV. A

							* Difilling 시 개작업	*유명한 결정: 찍힌,sheet 회자기				*용작일이 있거나	절착부위가 짧어질 시 2.7.2	Zii E		*.용 침투 부위 폐기. 특이사행기록	
작업자	작업자	작업자	京园		A 입자	호 전 전	A III III	사 의 다	함 전	故	A IN		F	(I)		호 전 전 전	전 전 전
お砂部刀	공정일지	공정일지	多路區		관리점사	관리공사	3	ı	바리장사	관리점사	1		位用加出品	티		(A) (A)	LOT 01章 学们随相
(四 (記 (記 (記	阿斯斯	(1) (1) (1)	시업 시 5호 이상		(전) (전)	(원) 중제 (건)	산	( <del> </del> ₹3	50 50 80	15 (15 (15)	산	13 038 135	阿斯斯	(1) (1) (1)	阿阿阿	산	정말
시간	H	93 St.	西山	15 81	\$0 \$0	জ ক তা	Filling &	₹0 ₩0	ফু ক ভা	의 호	51 Rf 00	100 100	시간	AIZ	시간	축0 골0	판바
60±2 sec	40±2°C	100±2bar	335±7um		Burr의 유/무	라/송 물편,終일 미	Via Filling 9/∓	(2) (2) (2) (3) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4	마/66 원전, 146일 미	미 인쇄,면집 유/무	10년 10년 10년 10년 11년 11년 11년 11년 11년 11년	-75±1mmHG0Ið	0.6±0.2min	2±0.5sec	2±0.5sec	080 01- 01- 01-	1.33 size : 1550µn ± 25um
部	邻	하	Height 게이지		etr 하	야[ 주]	でい 単いに 明の場 で	oft. 우기	98T 63	9\$T	部	(학) (학)	(d) (d)	部	部	郎	Height 列01万
가압 시간 인디게이터 확인	6후 日이K116 조랑 정선	가압력 인디게이터 확인	가압 후 면을 두고 축정		Vie 형태 검사	인쇄 법물을 삼.하.좌.우로 이동 시키며 모니터로 감사	Filing된 번들을 라이트 테이블에 올려놓고 빛의 투영을 이용하여 검사	적층 알리된 반개품을 육안으로 검사	인속 면들을 상,하,과,우로 이동 시키면 모니터로 감사	인쇄 법들을 삼,하,좌,우로 이동 시키며 모니터로 검사	. 연공 후 진공 비닐내의 움적일 확인.	인디게이터 확인	일다게이터 확인	일본 되어지다	인디게이터 확인	파 당 네 전 000	於
	기업환		四 UF 600 RI	절에 순천 기일	Via ⊗⊞	亞 ☆0 審	Via Filling &BI(CTQ)	라 한 라	의화 상대	日 令 田 谷	진공포장상대	전공 양물	진공시간	접착시간	명각시간	· 花 花 花 百 百	(20) (4) (1) (1)
		40 R	10 1		Punching	所 で 動	Via Filling	Align	이 하 중 기	Marking 인쇄			전 유 표 교		'		d. ⊗



STM-8100 BT

REV. A

在	以		Sheet coop	學 學 是 LOT 互助核政法	형상 매LOT 스이크() 영당자 별도관리	TOJ HI	외관검사 GN LOT Check Sheet	를 하는 물에서 다시 Check Sheet	# TOT # # 하십사 성조사	位文初 李和斯斯 TOT 新聞	LOT 機可能外 必因法	機な記さ 2000 2002 2003
지 한 음 음 20 20	지 한 급 급 성 공항	Traveler	0 0	TO TO	IN LOT	TOJ HI	24 5	100		100	8	
₹0 ₹0	古 20 题	表 分 器	0		2	E	IN LOT	DH LOT	TOJ II	LOT	10	100
			·	₹0 ₩0	₹0 20	40				舌	07 H	III LOT
河山村田	調査計画	Sheet상의 c과 일치.	æ			₹0 ₩0	20 ₩0	ML 20	₹0 ₩0	JII 20	₹0 ₹0	₹0 ₩0
	1	Spec	외관검사 기준서	NI:3.0~3.5 µm Au: 0.05~0.1µm	외관검사 기준서	수임검사기준서	외관검사 기준서	Spec Sheet상의 Spec과 일치	외관검사 기준서	Spec Sheet상의 Spec과 일치	출하검사 기준서	출하검사 기준세
Recorder	Recorder	Vernier Callipers	환미생 X20이상	oft 승기	Microscopic	Digtal Force Gauge	현미경 X20이상	ANT Handler	현미광 X20이상	Network Analyzer	Push pull gage	남조 Test기
소결료의 프로마일 확인	소골로의 프로마일 확인	Vernier Callipers 8ize 검사	현미경 X20이상 외관검사	日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日日	현미광 X20이상	도금 민정택 TEST	사용대명 X2001상 외관검사	ANT Handler측정 검사	현미경 X20이상 외관검사	Network Analayzer장비 흑쟁	인장택 측정장비	Reflow Test
55 分 下 訓	전 전 전 전	Size	マかから	出い	외관검사	인장택검사	외관점사	특성검사	사윤균명	를 성입자	17 (2)	00 00 00 FF
De-binding	7001 <1	DOG	3		면 a 100 H		京0 Fl0	작산점수		でいる。		
	활기 상당 소급적의 프로마일 확인	De-binding         될지 상태           소설로의 프로마일 확인           소설         상당	De-binding 탈지 상당 소골로의 프로마일 확인 소골 소골 소공 상당 소골로의 프로마일 확인 Por	De-binding         활지 상당         소립로의 프로마일 확인           소결         소결 상당         소결로의 프로마일 확인           POC         Size         Vernier Callipers 8ize 검사           POC         외관검사         현미경 X20이상 의관검사	Ace of a continuo 20 continuo	De-binding         빨지 상태         소결로의 프로마일 확인           소결         소결         소결           A 2절         상태         소결           A 2절         사용         사용           B 2 4 34         사용         사용           B 2 4 34         사용         사용           B 2 3 4 4         보다         소급           B 2 3 4 4         보다         보다           C 2 3 2 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	De-binding         탈지상당         소결론의 프로마일 확인           소결상당         소결론의 프로마일 확인           8ize         Vernier Callipers 8ize 감사           9DC         외관감사         현미경 X2001상 의관검사           도급투제         도급성전사확인           도급보고         외관검사           모양력감사         전미경 X2001상	De-binding         탈지상명         소결론의 프로마일 확인           소결상명         소결론의 프로마일 확인           Size         Vernier Callibers Size 검사           POC         외관검사         현미경 X20이상 외관검사           도급인고         외관검사         현미경 X20이상 외관검사           도급인고         외관검사         현미경 X20이상 외관검사           공정         외관검사         토리 인정력 TEST	De-binding         탈지상당         소결국의 프로마일 확인           소결 상당         소결국의 프로마일 확인           8ize         Vernier Cellipers 8ize 검사           9ize         Vernier Cellipers 8ize 검사           도급부계         도급성적사확인           도급하여         모급성적사학인           도급인고         외관검사         현미경 X20이상 의관검사           공장         모급성검사         도급 인정력 TEST           공수임사         토미경 X20이상 의관검사           로수임사         토미경 X20이상 의관검사           로수임사         로급성검사	De-binding     탈기 상담     소멸병의 프로마일 확인       소결 상담     소결 상담     소결 상담       8ize     Vernier Califoers 8ize 감사       9ize     Vernier Califoers 8ize 감사       도급부가     보급성감사     보급성감사       모급성감사     본급 인정력 TEST       요구입사     보급성감사       요구입사     ANT Handler추정 감사       요구입사     전미경 X2001상 의관감사       요구입사     전미경 X2001상 의관감사	A 2월 상당 소립 수 2월 상당 소립 보이 프로마일 확인 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	A 2월 상당 소립로의 프로마일 확인 2급 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2

ETHERTRONICS



STM-8100 BT

REV. A

	오 표장 시 재표장	라 라 100 더 400
	전사진	四小刀
	şı	を対している。
	1	1
60	₹0 ≅0	₹0 ₹0
	포장작업기관류	모델,수랑,LOT 기재 호
	ත් 017	වා ගේ
	포장작업기관에 준하여 포장상되 감사(누락/취집행 無)	출하지시시상의 모델,수량 확인
	보장상담감사	모말/LOT검사
	수진다	€5 491

ETHERTRONICS



STM-8100 BT

REV. A

### 13. 유해 물질 성적서

13.1 세라믹 파우더



Test Report No. F690501/LF-CT\$AYAA08-15067

Issued Date: May 23, 2008

Page 1 of 3

To: RN2 TECHNOLOGIES CO., LTD. 284-2, Galgot-ri

284-2, Galgot-ri Jinwe-myeon Pyeongtaek-city GYEONGGI-DO Korea

The following merchandise was submitted and identified by the client as :

Product Name : Ceramic Powder (LTCC)

 SGS File No.
 : AYAA08-15067

 Received Date
 : May 19, 2008

 Test Performing Date
 : May 20, 2008

Test Performed : SGS Testing Korea tested the sample(s) selected by applicant with following results

Teet Results : For further details, please refer to following page(s)

Buyer(s) : ETHERTRONICS

SGS Testing Korea Co. Ltd.

Jeff Jang / Chemical Lab Mgr

Monet Jeong Billy Oh / Testing Person

Pluto Kim

The document is bound by the Company under to Countrie Condition of Service printed societies on request and acceptance of Manchemany constraints, and conditionally.

Ministry, International and principles assess of defined document, and printed or the document of the societies and the company of the Company of the or the societies and or contribute or considerable and the company of the Company of the contribute or considerable and the company of the contribute of the contri



### STM-8100 BT

REV. A

Page 2 of 3



Test Report No. F690501/LF-CTSAYAA08-15067 Issued Date: May 23, 2008

: AYAA08-15067.001 Sample No. ; Ceramic Powder (LTCC) Sample Description

Item No./Part No.

; Material is Ceramic Powder (LTCC). Comments

#### Heavy Metals

Tect Items	Unit	Tect Method	MDL	Recults
Cadmium (Cd)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	0.5	N.D.
Lead (Pb)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	5	N.D.
Mercury (Hg)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	2	N.D.
Hexavalent Chromium (Cr VI)	mg/kg	US EPA 3060A(1996), US EPA 7196A(1992), UV	1	N.D.

#### Flame Retardants-PBBs/PBDEs

Test Items	Unit	Test Method	MDL	Recutto
Monobromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Dibromoblphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Tribromobiphenyi	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Tetrabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Pentabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Hexabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Heptabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Octabromoblphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Nonabromoblphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Decabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Monobromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Dibromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Tribromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Tetrabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Pentabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Hexabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Heptabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Octabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Nonabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Decabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.

- NOTE: (1) N.D. Not detected.(<MDL)

  - (2) mg/kg = ppm (3) MDL = Method Detection Limit

  - (4) = No regulation (5) \*\*\* = Qualitative analysis (No Unit) (6) Negative = Undetectable / Positive = Detectable



STM-8100 BT

REV. A



Test Report No. F690501/LF-CTSAYAA08-15067

Issued Date: May 23, 2008

Page 3 of 3

Sample No. Sample Description : AYAA08-15067.001 ; Ceramic Powder (LTCC)

Item No./Part No.

: N/A

Comments

; Material is Ceramic Powder (LTCC).

#### Halogen Contents

Test Items	Unit	Test Method	MDL	Results
Bromine(Br)	mg/kg	EN 14582:2007 , IC	30	N.D.
Chiorine(CI)	mg/kg	EN 14582:2007 , IC	30	N.D.



\*\*\* End \*\*\*

- (1) N.D. Not detected.(<MDL)
- (2) mg/kg = ppm (3) MDL = Method Detection Limit
- (4) = No regulation (5) \*\* = Qualitative analysis (No Unit)
- (6) Negative Undetectable / Positive Detectable



STM-8100 BT

REV. A

### 13.2 Au plating



Test Report No. F690501/LF-CT\$AYAA08-15065

Issued Date: May 23, 2008

Page 1 of 2

To: RN2 TECHNOLOGIES CO., LTD. 284-2, Galgot-ri

284-2, Galgot-ri Jinwe-myeon Pyeongtaek-city GYEONGGI-DO Korea

The following merchandise was submitted and identified by the client as :

Product Name : Au Plating Liquid

SGS File No. : AYAA08-15065

Received Date : May 19, 2008

Test Performing Date : May 20, 2008

Test Performed : SGS Testing Korea tested the sample(s) selected by applicant with following results

Test Results : For further details, please refer to following page(s)

Buyer(8) : ETHERTRONICS

SGS Testing Korea Co. Ltd.

Pluto Kim Monet Jeong Billy Oh / Testing Person

Jeff Jang / Chemical Lab Mgr



### STM-8100 BT

REV. A



Test Report No. F690501/LF-CT\$AYAA08-15065

Issued Date: May 23, 2008

Page 2 of 2

Sample No. Sample Description : AYAA08-15065.001

Item No./Part No.

: Au Plating Liquid

Comments

: N/A

: Material is Au plating liquid.

#### Heavy Metals

Test items	Unit	Test Method	MDL	Recuts
Cadmlum (Cd)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	0.5	N.D.
Lead (Pb)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	5	N.D.
Mercury (Hg)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	2	N.D.
Hexavalent Chromium (Cr VI)	mg/kg	US EPA 3060A(1996), US EPA 7196A(1992), UV	1	N.D.



\*\*\* End \*\*\*

NOTE:

- (1) N.D. Not detected.(<MDL)
- (2) mg/kg = ppm (3) MDL = Method Detection Limit

- (4) = No regulation (5) \*\* = Qualitative analysis (No Unit) (6) Negative = Undetectable / Positive = Detectable

evaluate on request and assemble of high-tenency constraint, and constraint. Assemble to them to the feetiles of the behindles constant herein refera the Company Stratigs of the first feetile of the services may be deter the beste of not exceede patter to a tenential from executing of their layer and diligative until the tenential consents Any



### STM-8100 BT

REV. A

13.3 Ni plating



Test Report No. F690501/LF-CTSAYAA08-15066

Issued Date: May 23, 2008

Page 1 of 2

RN2 TECHNOLOGIES CO., LTD. 284-2, Galgot-ri

Jinwe-myeon Pyeongtaek-city GYEONGGI-DO Korea

The following merchandise was submitted and identified by the client as :

: NI Plating Liquid Product Name SGS FIIe No. : AYAA08-15066 ; May 19, 2008 Received Date Test Performing Date : May 20, 2008

Test Performed : SGS Testing Korea tested the sample(s) selected by applicant with following results

Test Results : For further details, please refer to following page(s)

Buyer(8) : ETHERTRONICS

SGS Testing Korea Co. Ltd.

Pluto Kim Monet Jeong Billy Oh / Testing Person

Jeff Jang / Chemical Lab Mgr



### STM-8100 BT

REV. A



Test Report No. F690501/LF-CT\$AYAA08-15066

Issued Date: May 23, 2008

Page 2 of 2

Sample No. Sample Description : AYAA08-15066.001

; NI Plating Liquid

Item No./Part No. Comments

: N/A : Material is Ni plating liquid.

#### Heavy Metals

Test items	Unit	Test Method	MDL	Recutts
Cadmlum (Cd)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	0.5	N.D.
Lead (Pb)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	5	N.D.
Mercury (Hg)	mg/kg	US EPA 3052(1995), US EPA 6010B(1996), ICP	2	N.D.
Hexavalent Chromium (Cr VI)	mg/kg	US EPA 3060A(1996), US EPA 7196A(1992), UV	1	N.D.



\*\*\* End \*\*\*

NOTE:

- (1) N.D. Not detected.(<MDL)
- (2) mg/kg = ppm (3) MDL = Method Detection Limit

- (4) = No regulation (5) \*\* = Qualitative analysis (No Unit) (6) Negative = Undetectable / Positive = Detectable

evaluate on request and assemble of high-tenency constraint, and constraint. Assemble to them to the feetiles of the behindles constant herein refera the Company Stratigs of the first feetile of the services may be deter the beste of not exceede patter to a tenential from executing of their layer and diligative until the tenential consents Any



STM-8100 BT

REV. A

13.4 Ag Paste



Test Report No. F690501/LF-CT\$AYAA08-15064

Issued Date: May 23, 2008

Page 1 of 2

RN2 TECHNOLOGIES CO., LTD. 284-2, Galgot-ri

Jinwe-myeon Pyeongtaek-city GYEONGGI-DO Korea

The following merchandise was submitted and identified by the client as :

: Ag Paste Product Name

SGS FIIe No. : AYAA08-15064 ; May 19, 2008 Received Date : May 20, 2008 Test Performing Date

Test Performed : SGS Testing Korea tested the sample(s) selected by applicant with following results

Test Results : For further details, please refer to following page(s)

Buyer(8) : ETHERTRONICS

SGS Testing Korea Co. Ltd.

Pluto Kim Monet Jeong Billy Oh / Testing Person

Jeff Jang / Chemical Lab Mgr



STM-8100 BT

REV. A



Test Report No. F630501/LF-CTSAYAA08-15064

Issued Date: May 23, 2008

Page 2 of 2

Sample No. Sample Description : AYAA08-15064.001 : Ag Paste

Item No./Part No.

: N/A

Comments

: Material is Ag.

#### Heavy Metals

Tect items	Unit	Test Method	MDL	Recults
Cadmium (Cd)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	0.5	N.D.
Lead (Pb)	mg/kg	US EPA 3052(1995), US EPA 6010B(1996), ICP	5	N.D.
Mercury (Hg)	mg/kg	US EPA 3052(1995), US EPA 6010B(1996), ICP	2	N.D.
Hexavalent Chromium (Cr VI)	mg/kg	US EPA 3060A(1996), US EPA 7196A(1992), UV	1	N.D.



\*\*\* End \*\*\*

NOTE:

- (1) N.D. Not detected.(<MDL)
- (2) mg/kg = ppm (3) MDL = Method Detection Limit

- (4) - No regulation (5) \*\* Qualitative analysis (No Unit) (6) Negative Undetectable / Positive Detectable



### STM-8100 BT

REV. A

### 13.5 Marking Paste



Test Report No. F690501/LF-CTSAYAA08-15068

Issued Date: May 23, 2008

Page 1 of 3

To:

RN2 TECHNOLOGIES CO., LTD. 284-2, Gaigot-ri

284-2, Galgot-ri Jinwe-myeon Pyeongtaek-city GYEONGGI-DO

The following merchandise was submitted and identified by the client as :

Product Name : Marking Paste

SGS File No. : AYAA08-15068

Received Date : May 19, 2008

Test Performing Date : May 20, 2008

Test Performed

Test Results : For further details, please refer to following page(s)

Buyer(s) : ETHERTRONICS

SGS Testing Korea Co. Ltd.

Jeff Jang / Chemical Lab Mgr

Monet Jeong Billy Oh / Testing Person

Pluto Kim

This doublewed is becomed by the Company under the Committee Conditions of Service protect excellent on requirement and excellent of the Service protect excellent on the control of the Company of conditional control of the Company of the Company

: SGS Testing Korea tested the sample(s) selected by applicant with following results



### STM-8100 BT

REV. A



Test Report No. F690501/LF-CT\$AYAA08-15068 Issued Date: May 23, 2008

Page 2 of 3

; AYAA08-15068.001 Sample Description : Marking Paste Item No./Part No. : G-3920RN

#### Heavy Metals

Test Items	Unit	Test Method	MDL	Recuits
Cadmlum (Cd)	mg/kg	US EPA 3052(1996), US EPA 6010B(1996), ICP	0.5	N.D.
Lead (Pb)	mg/kg	US EPA 3052(1995), US EPA 6010B(1996), ICP	5	N.D.
Mercury (Hg)	mg/kg	US EPA 3052(1995), US EPA 6010B(1996), ICP	2	N.D.
Hexavalent Chromium (Cr VI)	mg/kg	US EPA 3060A(1996), US EPA 7196A(1992), UV	1	N.D.

#### Flame Retardants-PBBs/PBDEs

Test Items	Unit	Test Method	MDL	Recults
Monobromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Dibromobiphenyi	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Tribromobiphenyi	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Tetrabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Pentabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Hexabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Heptabromobiphenyi	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Octabromoblphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Nonabromoblphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Decabromobiphenyl	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Monobromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Olbromodlphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Tribromodiphenyi ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Tetrabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Pentabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Hexabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Heptabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Octabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Nonabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.
Decabromodiphenyl ether	mg/kg	US EPA 3540C, GC/MS	5	N.D.

NOTE: (1) N.D. - Not detected.(<MDL)

(2) mg/kg = ppm (3) MDL = Method Detection Limit

(4) - = No regulation (5) \*\* = Qualitative analysis (No Unit) (6) Negative = Undetectable / Positive = Detectable

evaluate on request and extensible of http://www.sp.com/street, and conditionalists. Abstracts in these to the fundament of the first of the street of the s



STM-8100 BT

REV. A



Test Report No. F630501/LF-CTSAYAA08-15068

Issued Date: May 23, 2008

Page 3 of 3

; AYAA08-15068.001 : Marking Paste Sample Description Item No./Part No. : G-3920RN

#### Halogen Contents

Test Items	Unit	Test Method	MDL	Recutto
Bromine(Br)	mg/kg	EN 14582:2007, IC	30	N.D.
Chiorine(CI)	mg/kg	EN 14582:2007, IC	30	N.D.



\*\*\* End \*\*\*

NOTE: (1) N.D. - Not detected.(<MDL)

(2) mg/kg = ppm (3) MDL = Method Detection Limit

(4) - = No regulation (5) \*\* = Qualitative analysis (No Unit)

(6) Negative - Undetectable / Positive - Detectable